

## 2. Burring



### ■ Usage

Holes through a pipe and a code.  
Drain holes, air holes or the like.

### ■ Shapes Overview

Forming tool forms a tube from the  
workpiece and makes a "rising part".

## Examples



It forms tubes of various  
inner diameters.  
After processing pre-hole,  
tube is formed by one  
punch.



Shapes which do not fit  
in tool range such as  
 $\phi 300$  can be processed  
by the continuous  
processing.



This photo is the example  
of burring for a variable  
resistor which is what we  
call a volume switch.

Request for a quotation is [here](#).